

# Hiro WiFi Presenter - 2.4GHz WiFi Presenter with Laser pointer and wireless mouse function

**\*\*\*Please make sure the transmitter is plug into the USB port, and the battery is input into the controller. Your computer should recognize the transmitter and install the driver automatically.**

## **Link the transmitter and controller.**

**If, the controller's mouse function isn't working, it is necessary to re-sync the transmitter and controller. First, press the little button on you transmitter...**



**...and your transmitter's red LED should be on:**



**Then, look at the side of controller...**



**...and press & hold the 2 buttons for couple seconds:**



**...then the LED on you controller should be flashing in green...**



**...and the red LED on your transmitter should be flashing couple times then go off...**



**Finally, release the 2 buttons on controller & wait for several seconds. Then, both transmitter and controller should be linked properly. Then you can use the pointer/mouse function.**